

Cookie Cutter - Puff Pastry - 2 pieces

Article number: 550025

ABS plastic – food safe – dishwasher safe
Size: 8,4 x 8,4 x 2,2 cm
Colour: red
glossy

Description

With these cutters you can easily and accurately cut out puff pastry for small baked goods. Put a dab of filling in the middle, fold the wings of the pastry over the filling, brush with a little egg and put in the oven.

Enjoy baking and decorating!

This cookie cutter is made of high quality plastic. We advise to wash up the cutter with running, warm water straight after use.

In folding box for hanging up.

