

we love baking – Snowman – 3D- Article number: 661820 Cake pan

Metal – not dishwasher safe

Size: 19 x 21 x 12 cm

very high-quality and long-lasting non-stick coating for pure baking fun

With a quick-release fastener for easy shaping.

Snowman's size: ca. 13.5 x 19 x 12 cm.

PFAS free.

Description

Baking with love...

Baking together with one's mother or grandmother often is one of the most beautiful childhood memories: kneading butter, sugar, eggs and flour to conjure up the very best and tastiest pastry creations, preferably with lots of chocolate or fresh fruit – who does not relish in such memories? For all who love to bake for themselves and for others, we have developed our new product line "We love baking". Whether it be muffins, brownies or cake pops – bakers large and small will find their preferred baking tin. The elegant, silver-coloured "We love baking" moulds contribute to a heavenly baking experience.

Rediscover your love of baking with our new series "We love baking". Baking is cake-shaped happiness.

The moulds are fitted with a durable, very high quality coating to make baking and cake removal easy and to always get evenly-baked cakes. Clean baking tins with hot water, a mild detergent and a soft cloth. Please do not use abrasive cleansing sponges, scrubbers or scouring agents. Do not put in the dishwasher. Temperature-resistant up to 250 °C.

PFAS free.

In folding box with recipe

Manual

Usage and care instructions

Rinse with hot water before using for the first time. Before baking, spray the tin with STÄDTER baking separating spray or grease lightly and cover with flour.

Do not use any sharp objects or metal utensils to remove the cake from the tin.

Cleaning

Clean the tin with hot water, just a little bit of washingup liquid and a cloth. Do not use any abrasive cleaning sponges, scrubbers or scourers. Do not put in the dishwasher. Dry thoroughly after cleaning.

