

Linzer cookie cutter – Heart – corrugated – double sided

Article number: 954138

ABS plastic – food safe – dishwasher safe
Size: ø 5,5 cm / H 3 cm
Colour: red

Description

With this cookie cutter you can easily cut out the top and bottom of the popular Linzer biscuits. Simply turn the cookie cutter over – and off we go! With the outer ring you can now cut out the lower part of the Linzer. Bake both parts and put them together with the help of jam, marmelade, icing or nougat cream.

Enjoy baking and decorating!

You can find delicious recipes in our recipe portal.

This cookie cutter is made of high quality plastic. We advise to wash up the cutter with running, warm water straight after use.

Fixed on cardboard for hanging up.

