

Grid Pastry Cutter – Round

Article number: 547018

PS plastic – food safe – dishwasher safe

Size: ø 30 cm

Colour: white

Description

Suitable for linzer cakes, dutch biscuits, sponge cake grids and marzipan grids.

The grid pastry cutter is made of high quality plastic. We advise to wash it up with mild detergent, warm water and dishwashing brush straight after use. Of course you can also wash it up in the dishwasher.

With recipe

