

Product information

Linzer cookie cutter with Article number: 954077 ejector - Pretzel - not demountable

Material: stainless steel / plastic - hand wash

Size: 6,5 cm

For cut out Linzer biscuits

Cutting out dough, sugarpaste or marzipan. Also suitable for crafting or modelling with modelling clay, salt dough or Fimo clay.

Description

This cookie cutter is for cutting out the upper part of the famous Linzer cookies. The integrated ejector mechanism makes it easy to place them on the baking sheet. For cutting out the lower part of the Linzer cookie, you just neet the appropriate outer ring. Bake both parts and put them together with the help of jam, marmelade, icing or nougat cream. Enjoy baking and decorating.

You can find delicious recipes in our recipe portal.

For more motives, have a look in our cookie cutter range.

The cookie cutter is made of high quality stainless steel and food-safe and stable plastic. We advise to wash it up with warm running water straight after use. Of course it can also be washed in a dishwasher.

Manual

SAFETY NOTE: Sharp edges if used incorrectly!







Tel. +49 6407 4034-1000

Fax +49 6407 4034-1009 E-Mail: info@staedter.de