

Cookie Cutter – Enchanted house / Gingerbread house – Set, 7 parts

Article number: 954220

PP plastic – food safe – dishwasher safe
Size: 15 x 19 x 21 cm
Colour: green

Content:

each 1 cookie cutter for the roof, the gable side, the side walls, for the chimney and for the firs trees, 2 cookie cutters for the windows

Description

With these cookie cutters you can cut out all parts you need for a gingerbread house. After baking, put them together with icing and decorate your gingerbread house with sweets just as the fancy takes you – that's it.

Enjoy your baking and decorating.

You can find delicious recipes in our recipe portal.

This cookie cutter is made of polypropylene. The cutter is very robust and well-suited for children's hands.

We advise to wash up the cutter with running, warm water straight after use.

In folding box. With instructions and recipe



Manual

SAFETY NOTE: Sharp edges if used incorrectly!

Manufacturer: STÄDTER GmbH · Am Kreuzweg 1 · 35469 Allendorf/Lumda · Tel. +49 6407 4034 1000 · info@staedter.de