

Linzer cookie cutter with ejector – Article number: 966070 Pretzel – demountable

Material: stainless steel / plastic - hand wash
Size: 6,5 cm

For cut out Linzer biscuits

Cutting out dough, sugarpaste or marzipan. Also suitable for crafting or modelling with modelling clay, salt dough or Fimo clay.

Description

With these cookie cutters you can cut out both parts of the famous Linzer cookies. Just press the desired motive into the outer ring – and off we go! For cleaning, you can disassemble the cutter. With the outer ring you can now cut out the lower part of the Linzer. Bake both parts and put them together with the help of jam, marmelade, icing or nougat cream.
Enjoy baking and decorating!

You can find delicious recipes in our recipe portal.

The cookie cutter is made of high quality stainless steel and food-safe and stable plastic. We advise to wash it up with warm running water straight after use. Of course it can also be washed in a dishwasher.

